

Breather Block-off Adapter Kit**034 MOTOR SPORT**

The Billet Breather Block Off Kit for 8J Audi TTRS 2.5 TFSI is designed to remove the "shortcut" for oil to directly enter the intake manifold, forcing crankcase ventilation to go through an aftermarket catch can setup and allowing for a boost tap or intake injection point.

Installation Spiciness Rating: MILD

Installation of your 034 Block-off Adapter is a straightforward process that will take approximately 30 minutes to complete.

Supplied Parts:

- (2x) 034 Breather Adapters
- (2x) 034 Breather Adapter Shells
- (2x) 034 Breather Adapter Clips
- (2x) 1/8" NPT Plugs
- (2x) 14mm O-Rings

Tools Needed:

- 13mm Wrench
- 3/16 Allen
- Small Pliers

About This Guide

This Install Guide documents the installation process on a 8J Audi TTRS. There may be minor differences depending on specific vehicle, market, options, etc.

Getting Started

Confirm you have received all the parts included with your purchase by reading the complete guide, if there are missing components, please contact:

customerservice@034motorsport.com

Assembly Steps



Step A

Install the o-ring onto the breather plug.



Step B

Using a 3/16" Allen tool, install the 1/8" NPT plug into the breather plug. Use a 13mm wrench to steady the plug.



Install Steps

Step 1

Remove the carbon fiber engine cover.



Step 2

Locate the breather hose between the valve cover and intake manifold.



Step 3

Squeeze the tabs and pull the hose to remove from both the valve cover and intake manifold.

**Step 4**

Insert the plug into the hole.

**Step 5**

Slide the cover over the plug. On the valve cover plug, make sure the tabs are horizontal to prevent the cover from rotating.

Step 6

Slide the clip through the shell to lock it in place.

**Step 7**

Use a set of pliers to squeeze the tabs on the clip to make sure it is secure.



Step 8

Place the carbon fiber engine cover back into place.

Step 9

You're done. Enjoy the benefits of your new 034 product.

