

B8/8.5 3.0T Billet Oil Filter Housing



034 MOTORSPORT

034Motorsport's Billet Oil Filter Housing for the B8/B8.5 3.0T is designed to directly replace your factory plastic oil filter housing which is prone to warping, leaking and cracking. The 034Motorsport Billet Oil Filter Housing is CNC machined from 6061-T6 aluminum and is hard anodized bright black for lifelong great looks. Transform your engine bay with the beautiful 034Motorsport Billet Oil Filter Housing.

Installation Spiciness Rating: MILD



Installation of your 034Motorsport Billet Oil Filter Housing is a straightforward process that will take approximately 30 minutes to complete.

Supplied Parts:

- (1x) Billet Oil Filter Housing

Tools Needed:

- 36mm Socket
- Shop rag

Getting Started

Confirm you have received all the parts included with your purchase by reading the complete guide, if there are missing components, please contact:

customerservice@034motorsport.com

About This Guide

This Install Guide documents the installation process on a B8 Audi S5. There may be minor differences depending on specific vehicle, market, options, etc.

We recommend replacing your oil filter, along with the gasket and o-ring. If yours are fairly new, you can reuse them.

Install Steps

Step 1

Open your hood.



Step 2

Using a 36mm socket, loosen the factory oil filter housing.



Step 3

Lay down some rags to soak up any stray oil drips.



Step 4

Quickly remove the housing.



Step 5

Remove the oil filter.

**Step 6**

Remove the o-ring from the oil filter provision on the engine.

**Step 7**

Install the new o-ring onto the oil filter provision on the engine.

**Step 8**

Rub some oil along the o-ring to prevent tearing.

Step 9

Install the new gasket into the oil filter housing. It may seem like it's too big, but it will fit with some patience.



Step 10

Gently remove the oil filter tube from the old housing.

**Step 11**

Transfer the tube to the 034 oil filter housing. There should be an audible indication that it has bottomed out.

**Step 12**

Install a fresh oil filter. There should be another audible indication that the filter has bottomed out.

**Step 13**

Thread the 034 oil filter housing onto the engine.



Step 14

Using a 36mm socket, secure the housing.
Torque to **25Nm+5**.



Step 15

Clean up any stray oil.



Step 16

Admire that sexy new engine accessory.



Step 17

Close your hood and you're done. Enjoy!

