

Carbon Fiber Fuse Box Cover**034 MOTORSPORT**

This high quality carbon fiber piece is designed to perfectly complement 034Motorsport's X34 Intake System, Engine Cover, and Battery Cover for a true OEM+ engine bay appearance.

Installation Spiciness Rating: MILD

Installation of your 034Motorsport Carbon Fiber Fuse Box Cover is a straightforward process that will take approximately 30 minutes to complete.

Supplied Parts:

- 034Motorsport Carbon Fiber Fuse Box Cover

Tools Needed:

- Isopropyl Alcohol
- Towel

About This Guide

This Install Guide documents the installation process on a Mk7 VW Golf R. There may be minor differences depending on specific vehicle, market, options, etc.

Getting Started

Confirm you have received all the parts included with your purchase by reading the complete guide, if there are missing components, please contact:

customerservice@034motorsport.com

Install Steps

Step 1

Open your hood to access the fuse box cover.



Step 2

Using a towel and isopropyl alcohol, thoroughly clean the factory fuse box cover.



Step 3

Peel the backing off of the 3M Adhesive Strips on the carbon fiber fuse box cover, exposing the adhesive.



Step 4

Remove the factory fuse box cover by pressing in on the tabs at either end and lifting up.



Step 5

Slip the Carbon Fiber Fuse Box Cover onto the factory fuse box cover and press firmly to ensure the adhesive sticks.

**Step 6**

Reinstall the completed Fuse Box Cover.

**Step 7**

You're done. Enjoy!

