

[Sway Bar End Links, Motorsport, Rear, Adjustable B4/B5 Audi Quattro](#)



034 MOTORSPORT

These end links feature billet aluminum construction for unmatched strength compared to stock plastic and thin steel units, and will allow you to remove any preload for sway bar, especially when corner balancing.

About This Guide

This Assembly Guide documents the process of the proper configuration prior to installation with the 034Motorsport parts that you have just purchased! Pictures and part numbers may vary, but the process remains the same.

Getting Started

- Confirm you have received all of the parts included with your purchase, if there are missing components, please contact customerservice@034motorsport.com

Collect the necessary tools required for installation by reading the complete Assembly Guide.

Supplied Parts:

- (2x) billet sway bar end links with spherical bearings and circlips
- (2x) spherical heim joints with jam nuts
- (4x) spacers
- (4x) M10 bolts
- (4x) nylon locking nuts
- (4x) washers
- (2x) dust boots
- (1x) packet of anti-seize

Tools Needed:

- (2x) capable hands

* We ship the dust boots uninstalled; once you have the fitment set, install the dust boots before final installation (optional).



Step A

Open hardware packages



Step B

Apply half packet of anti-seize to spherical heim joint



Step C

Run the jam nut down the shaft to disperse the anti-seize along the entire threaded portion

**Step D**

Install the heim joint into the billet end links, leaving about 4-5 threads exposed



*For lowered vehicles, always check all clearances over the full articulation of the suspension in order to identify possible interference