

CTSTURBO

INSTALLATION GUIDE

CTS Resonator Delete MK7 Golf R, 8V S3
CTS-EXH-TP-0007



20630 Mufford Crescent, Unit #309
Langley, British Columbia V2Y 2V9

www.CTSTURBO.com

WHAT IS INCLUDED

1. Resonator Delete Pipe
2. Exhaust band clamps

**TOOLS REQUIRED**

1. Pipe cutter
2. 15mm socket
3. Permanent marker
4. Exhaust hanger pliers

NOTES

Vehicle used in this guide is a 2016 VW Golf R. Other cars will follow the same steps. We highly recommend installation using a hoist. Professional installation recommended. Always make sure the car is safe to work on. Do not work on a hot motor.

STEP 1

Place a mark 5.5" back from the exhaust hanger.

**STEP 2**

Use a pipe cutter to cut through the exhaust at the mark you made.



STEP 3

Use some wire to suspend your downpipe to the downshaft temporarily



VAG
AUTOSPORT.FR
PIÈCES D'ORIGINE ET PERFORMANCE

STEP 4

Use exhaust hanger pliers to release the exhaust hanger from the rubber mount



STEP 5

Loosen the stock exhaust clamp and remove the suitcase muffler.

If the stock clamp is in good shape you can reuse it or replace it with one of the ones provided in the kit.



VAG
AUTOSPORT.FR
PIÈCES D'ORIGINE ET PERFORMANCE

STEP 6

Insert the CTS pipe into the rubber mount and slide on the exhaust clamps.



STEP 7

Tighten both the front and rear clamps down with a 15mm socket.

**STEP 8**

You are done!

