

034Motorsport Turbo Inlet Hose, MQB I4**034 MOTOR SPORT**

The 034Motorsport Turbo Inlet Hose for 1.8T and 2.0T MQB vehicles is a multi-ply, wire-reinforced silicone hose designed to be a drop-in replacement for the unattractive and restrictive OEM corrugated plastic hose. The 034Motorsport Turbo Inlet Hose smoothly transitions from the intake to the turbo inlet pipe, providing increased airflow capability to support other power improving modifications. Wire reinforcement ensures the 034Motorsport Turbo Inlet Hose retains its shape, resisting vacuum-induced collapse when turbocharger air demand is increased.

**Installation Spiciness Rating: MILD**

Installation of your Turbo Inlet Hose is a straightforward process that takes approximately 30 minutes to complete.

**Supplied Parts:**

- 034 Turbo Inlet Hose
- (2x) Hose Clamps

**Tools Needed:**

- 8mm Socket
- 7mm Socket
- Pliers

Getting Started

Confirm you have received all the parts included with your purchase by reading the complete guide, if there are missing components, please contact:

[customerservice@034motorsport.com](mailto:customerservice@034motorsport.com)

About This Guide

This Install Guide documents the installation process on a MK7.5 VW GTI. There may be minor differences depending on specific vehicle, market, options, etc.

**\*Be sure to clean out any intake related components to remove any possible contaminants.**

**Install Steps****Step 1**

Open your hood.

**Step 2**

Using hose clamp pliers, loosen the stock clamp and move it up the tube, out of the way.

**Step 3**

Using a 7mm socket, loosen the hose clamp at the turbo inlet. Hint: a flexible extension, or regular extension with a wobble will help with reaching the clamp.

**Step 4**

The stock inlet hose can now be pulled out.



**Step 5**

Installation of the 034Motorsport Turbo Inlet Hose is the reverse of the removal of the stock hose. You may find it easier to install with the use of a heat gun on the turbo inlet end of the hose. Using an 8mm socket, tighten hose clamps. Enjoy!

